

Ford Super Duty 3D-Cell Mag Lite Install

2004 F250 4x4 XLT Sport Crew Cab

[Back to 2004 F250 Main Page](#)

This is certainly not one of the most exciting mods but here's a few pics anyway. I used the Mag Lite #ASXD026 clamp mounts to install a Mag Lite on the plastic trim beside the driver's seat.

Here's the spot I chose to install it. This was a nice out of the way spot where it won't get kicked.



I first removed the lower trim piece along the bottom of the door and peeled the weather stripping back.





Next I removed the trim and peeled back the weatherstrip for the rear door.





Next I pulled the center trim piece away from the door post enough to get my hand in there for the install. It pops out by pulling it toward the center of the cab. Don't forget to pull out this clip hiding at the bottom of this trim piece.



Next I marked and drilled the holes for the two Mag Lite mounts.



Then I bolted on the mounts and put it all back together and snapped the Mag Lite in place.





Questions or Comments? Email jmray@frontiernet.net