

Most any metal will work for the elements. Try to use something near 1/8" diameter and make sure they are free of all coatings and oxidation where they connect to the phase line.

Cut wire for elements 19" and bend in the middle so that there is 9 1/2" on each side. 8 Total are needed

See other page for phase line details